

Stereo Headphones

OWNER'S MANUAL — Please read before using this equipment.

Your RadioShack Stereo Headphones combine a dynamic sound element with lightweight comfort and durable construction for an acoustically-sensitive sound experience and exceptional value.

FEATURES

Unique Padded Headband Design — allows you to wear the headband for longer periods with maximum comfort.

Wide Frequency Response and Low THD — deliver sound reproduction with a true-to-life presentation.

High Energy, Rare Earth Neodymium Magnets — provide accurate sound reproduction and full frequency response.

In-line Volume Control— lets you adjust the listening level without having to go to the sound source.

Soft Foam Ear Cushions — provide a comfortable listening experience.

Pivoting Earpieces — provide the best possible fit and maximum sound transfer.

12-Foot Straight Y-Cord — gives you flexibility of movement while listening.

Gold-Plated 1/4-Inch Plug — for better, more durable electrical connection.

OPERATION

Caution: Turn down the volume on the sound source (radio, CD player, or TV) you plan to use before plugging in the headphones.

Insert the plug into the EARPHONE or similarly marked output jack on your sound source. Then adjust the headband for the best fit.

Note: The headphones have a 1/4-inch stereo plug. To connect them to a 1/8-inch stereo output jack, use an adapter (available at your local RadioShack store).

USING THE IN-LINE VOLUME CONTROL

The headphones' in-line volume control lets you adjust the listening level without touching the volume control of the sound source. Set the volume control of the sound source to a comfortable level. Then as desired, slide the in-line volume control to decrease or increase the headphones' volume level.

ACCESSORIES

Your local RadioShack store has many adapters, splitters, replacement ear pads, and cable extensions to enhance the use of your headphones.

LISTENING GUIDELINES

Listening Safely

To protect your hearing, follow these guidelines when you use headphones.

- Set the volume to the lowest setting before you begin listening. After you begin listening, adjust the volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high volume listening can lead to permanent hearing loss.
- Once you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

Even though some headphones let you hear some outside sounds when listening at normal volume levels, they still can present a traffic hazard.

SPECIFICATIONS

Frequency Response.....	20–20,000 Hz
Maximum Input Power	2.45V (100mW)
Impedance	60Ω
Nominal Sensitivity db SPL (1 mW)	99dB
Cord Length	12.0 ft
Total Harmonic Distortion at 95 dB SPL, 400 Hz, and 1 KHz	<0.2%
Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.	

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99